

INFLATABLE SAFETY GUIDELINES

- 1. Select an area clear of all structures, trees, overhead wires, stumps, rocks, animal droppings, etc.
- **2.** Before staking into the ground, obtain location of and mark all underground utilities, irrigation pipes, electrical wires, gas lines, or telephone cables. (Customer is responsible for contacting JULIE within 14 days prior to staking, but no less than 72-hours before).
- **3.** If you're on concrete or gravel, customer will need to provide a tarp under the inflatable. Do not place it directly on concrete or gravel.
- **4.** After it's inflated, anchor each corner of the inflatable with the stakes or sandbags provided. Do not use the inflatable without anchoring it.
- 5. Customer must provide an adequate three-wire extension cord (min. 12 gauge for 50') on site.
- 6. Leave the blower continuously running until you need to deflate the unit.
- 7. Make sure all zippers are zipped and trunks are tied off, if inflatable isn't blowing up.
- **8.** Inflatables are designed for use by children. Adults are generally too heavy and could be injured or injure others. Parents can accompany young children.
- 9. Children must be supervised by a responsible adult at all times.
- **10.** Group children by size; do not allow different sized children on or inside the inflatable at the same time.
- **11.** Limit the number of children using the inflatable at the same time (see weight capacity listed on inflatable).
- 12. Follow all rules listed on the side of the inflatable.
- 13. Remove shoes before using the inflatable.
- **14.** No sharp or hard objects (glasses, jewelry, watches, shoes, casts, etc.) are permitted on the inflatable.
- **15.** No flips, wrestling, somersaults, or body slamming allowed.
- **16.** Do not attempt to climb sides of any inflatable.
- 17. Jumping is only allowed inside the area enclosed by the safety netting. Do not jump on the loading platform.
- **18.** All inflatables are physically challenging. Any person with a health impairment, disease, high blood pressure, back, neck or other bone/joint problems, or any other conditions that might cause problems when physically challenged should consult their physician before entering inflatables.
- **19.** Food, drink, gum, candy, etc. are choking hazards and therefore are not permitted while using the inflatables.
- **20.** Do not permit children to play near the fan or behind the rear of the unit where they cannot be readily supervised.
- 21. To prevent the spread of germs, children should wash their hands and faces after using the inflatable.
- **22.** Do not use inflatable during periods of heavy rain, excessive winds (20mph or greater), or temperatures less than 50 degrees. In the event of severe weather, (lightning, thunder, rain or high winds) instruct all occupants to immediately exit the inflatable and disconnect power after all occupants have exited. Do Not inflate until the weather clears and inflatable is dry.
- **23.** If anchors come loose or should the inflatable begin to deflate during operation, immediately and calmly instruct all participants to exit the inflatable.
- **24.** Please make sure you have a large enough vehicle to transport if customer will pick up and return (please check with our staff what type of vehicle would be recommended for the inflatable requested).

Customer Signature:	Date: